




CIRCLE CUTTER ASSEMBLY (CMP-3)



How to:

CHANGE THE BLADE

Move the blade safety lock down so it covers the blade. Pull back the black tab on the opposite side of the safety lock. This will release the blade and allow you to replace with a new one. **Remember** to save the original plastic container to store the used blades.



OLFA®

Best made cutting tools in the world.®

www.olfa.com