


28, 45, 60mm ROTARY CUTTER ASSEMBLY (RTY-1/G, RTY-2/G, RTY-3/G)

BLADE REPLACEMENT

Take apart your cutter one piece at a time, laying out the parts in proper order and the correct position as they detach. Reassemble with new blade. Dispose of the old blade using the package that the new blade came in; tape it securely together and dispose.



OLFA[®]
Best made cutting tools in the world.[®]

OLFA Tip: The washer should always face out (REACH FOR THE SKY).

Note: Reverse order to opposite side of cutter for left-handed use.